


 373 ATASCOCITA RD. • HUMBLE, TX • 77396
 TEL (281) 441-6500 • FAX (281) 441-6510
 << www.aspenmfg.com >>

FMB Air Handler Parts Price List

Part Number	Description	Unit	Net Price
125054	Blower Assembly	FMBXX 18/24/25	Call Aspen
125055	Blower Assembly	FMBXX 30/36/37/38	Representative
125090	Blower Assembly	FMBXX 42/48/60/61/62/63/64	
8201	9 x 6 blower housing & wheel	FMBXX 18/24/25	
8200	10 x 8 blower housing & wheel	FMBXX 30/36/37/38	
8527	12 x 9 blower housing & wheel	FMBXX 42/48/60/61/62/63/64	
8098	motor - 230V - 1/5 HP	FMBXX 18/24/25	
8099	motor - 230V - 1/3 HP	FMBXX 30/36/37	
8524	motor - 230V - 3/4 HP	FMBXX 38/42/48/60/61/62/63/64	
8532	motor mount band - 1ea.	FMBXX 38/42/48/60/61/62//6364	
8533	motor mount leg - 3ea.	FMBXX 38/42/48/60/61/62/63/64	
8116	capacitor – 5 mfd / 370V	FMBXX 18/24/25	
8117	capacitor – 7.5 mfd / 370V	FMBXX 30/36/37	
8530	capacitor – 15 mfd / 370V	FMBXX 38/42/48/60/61/62/63/64	
8271	breaker - 15A - 2 pole	FMB00 kw	
8273	breaker - 30A - 2 pole	FMB05 kw	
8275	breaker - 50A - 2 pole	FMB08 kw	
8276	breaker - 60A - 2 pole	FMB10 kw	
8273	breaker - 30A - 2 pole - 1ea.	FMB15 kw	
8276	breaker - 60A - 2 pole - 1ea.	FMB15 kw	
8276	breaker - 60A - 2 pole - 2ea.	FMB20 kw	
8273	breaker - 30A - 2 pole - 1ea.	FMB25 kw	
8276	breaker - 60A - 2 pole - 2ea.	FMB25 kw	
8276	breaker - 60A - 2 pole - 3ea.	FMB30 kw	
8513	pull out disconnect - 10kw or less	FMB all	
8432	terminal block-2 pole-10kw or less	FMB all	
8231	blower time delay relay	FMB all	
8232	heater sequencer	FMB05/08/10 kw	
8232	heater sequencer - 2ea.	FMB15/20 kw	
8232	heater sequencer - 3ea.	FMB25/30 kw	
8246	transformer 230V - 40VA	FMB all	
8514	limit control - 140°	FMB all	
8239	heater - 5 kw	FMB05 kw	
8241	heater - 8 kw	FMB08 kw	
8242	heater - 10 kw	FMB10 kw	
8239	heater - 5 kw - 1ea.	FMB15 kw	
8242	heater - 10 kw - 1ea.	FMB15 kw	
8242	heater - 10 kw - 2ea.	FMB20 kw	
8239	heater - 5 kw - 1ea.	FMB25 kw	
8242	heater - 10 kw - 2ea.	FMB25 kw	
8242	heater - 10 kw - 3ea.	FMB30 kw	
125041	A coil assembly - 2 row 12 x 16	FMBXX 18/24	
125041+X2	A coil assembly - 2 row 12 x 16	FMBXX 18/24 W/TXV	
125041+X3	A coil assembly - 2 row 12 x 16	FMBXX 18/24 W/TXV	
125139	A coil assembly - 3 row 12 x 16	FMBXX 25	
125139+X2	A coil assembly - 3 row 12 x 16	FMBXX 25 W/TXV	
125139+X3	A coil assembly - 3 row 12 x 16	FMBXX 25 W/TXV	
125042	A coil assembly - 3 row 16 x 16	FMBXX 30/36/38	

125042+X2	A coil assembly - 3 row 16 x 16	FMBXX 30/36/38 W/TXV	
125042+X3	A coil assembly - 3 row 16 x 16	FMBXX 30/36/38 W/TXV	
125043	A coil assembly - 3 row 18 x 16	FMBXX 37	
125043+X2	A coil assembly - 3 row 18 x 16	FMBXX 37 W/TXV	
125043+X3	A coil assembly - 3 row 18 x 16	FMBXX 37 W/TXV	
125097	A coil assembly - 2 row 16 x 22	FMBXX 42	
125097+x2	A coil assembly - 2 row 16 x 22	FMBXX 42	
125097+x3	A coil assembly - 2 row 16 x 22	FMBXX 42	
125098	A coil assembly - 3 row 16 x 22	FMBXX 48	
125098+x2	A coil assembly - 3 row 16 x 22	FMBXX 48	
125098+x3	A coil assembly - 3 row 16 x 22	FMBXX 48	
125099	A coil assembly - 3 row 18 x 22	FMBXX 60	
125099+X2	A coil assembly - 3 row 18 x 22	FMBXX 60 W/TXV	
125099+X3	A coil assembly - 3 row 18 x 22	FMBXX 60 W/TXV	
125081	A coil assembly - 4 row 20 x 22	FMBXX 61	
125081+X2	A coil assembly - 4 row 20 x 22	FMBXX 61 W/TXV	
125081+X3	A coil assembly - 4 row 20 x 22	FMBXX 61 W/TXV	
125200	A coil assembly - 4 row 20 x 22	FMBXX 62	
125200+X2	A coil assembly - 4 row 20 x 22	FMBXX 62 W/TXV	
125200+X3	A coil assembly - 4 row 20 x 22	FMBXX 62 W/TXV	
125205	A coil assembly - 4 row 20 x 22	FMBXX 63	
125205+X2	A coil assembly - 4 row 20 x 22	FMBXX 63 W/TXV	
125205+X3	A coil assembly - 4 row 20 x 22	FMBXX 63 W/TXV	
125201	A coil assembly - 4 row 20 x 23	FMBXX 64	
125201+X2	A coil assembly - 4 row 20 x 23	FMBXX 64 W/TXV	
125201+X3	A coil assembly - 4 row 20 x 23	FMBXX 64 W/TXV	
PS-4-055	piston assembly - .055	FMBXX 18	
PS-4-059	piston assembly - .059	FMBXX 24/25	
PS-6-068	piston assembly - .068	FMBXX 30	
PS-6-074	piston assembly - .074	FMBXX 36/37/38	
PS-4-080	piston assembly - .080	FMBXX 42	
PS-6-084	piston assembly - .084	FMBXX 48	
PS-6-092	piston assembly - .092	FMBXX 60	
PS-8-092	piston assembly - .092	FMBXX 61/62/63/64	
125032	wire harness assembly	FMB00 kw	
125033	wire harness assembly	FMB05 kw	
125034	wire harness assembly	FMB08/10 kw	
125035	wire harness assembly	FMB15 kw	
125036	wire harness assembly	FMB20 kw	
125037	wire harness assembly	FMB25 kw	
125038	wire harness assembly	FMB30 kw	
126007	top door - solid	FMB 18/38	
126055	top door - 1p bkr	FMB 18/38	
126045	top door - 2p bkr(1)	FMB 18/38 00-10kw	
126046	top door - 2p bkr(2)	FMB 18/38 15-20kw	
125051	Coil door assembly	FMB 18/24	
126583	Coil door assembly	FMB 30-36-38	
126584	Coil door assembly	FMB 37	
126015	filter door	FMB 18/38	
126044	top door (disconnect)	FMB 18/38	
126031	top door - solid	FMB 42-64	
126041	top door - 2p bkr(1)	FMB 42-64 00-10kw	
126042	top door - 2p bkr(2)	FMB 42-64 15-20kw	
126043	top door - 2p bkr(3)	FMB 42-64 25-30kw	
126044	top door (disconnect)	FMB 42-64	
125087	Coil door assembly	FMB 42-64	
126581	Coil door assembly	FMB 60	
126582	Coil door assembly	FMB 61-64	

126029	filter door	FMB 42-64	
126051	top door - 1p bkr	FMB 42-64	
126056	top door - 3p bkr	FMB 42-64	
125076	downflow coil kit	FMB 18/38	
125077	downflow coil kit	FMB 42-64	
126013	A - coil drain pan	FMB 18/38	
126012	horizontal drain pan	FMB 18/38	
126025	A – coil drain pan	FMB 42-64	
126036	horizontal drain pan	FMB 42-64	
126053	Breaker stand	FMB15kw	
8579	Single Point power connection option	FMB 20KW and under	
8503	Hole plug	FMB all	