

Aspen FMB Air Handler Parts List

Part Number	Description	Unit
8201	9 x 6 blower housing & wheel	FMWXX 18/24
8200	10 x 8 blower housing & wheel	FMWXX 30/36/37
8527	12 x 9 blower housing & wheel	FMWXX 42/48/60/61
8094	motor - 120V - 1/5 HP	FMWXX 18/24
8095	motor - 120V - 1/3 HP	FMWXX 30/36/37
8537	motor - 120V - 3/4 HP	FMWXX 42/48/60/61
8115	capacitor - 10 mfd / 370V	FMWXX 18/24/30/36/37
8530	capacitor - 15 mfd / 370V	FMWXX 42/48/60/61
8179	wire harness assembly	FMW all
8518	breaker - 15A - 1 pole	FMW all
8513	pull out disconnect - 10kw or less	FMW all
8432	terminal block-2 pole-10kw or less	FMW all
8231	blower time delay relay	FMW all
8231	pump time delay relay	FMW all
8247	transformer 120V - 40VA	FMW all
8567	replacement pump cartridge	FMW all
3925	circulator pump with check valve	FMW all
125041	A coil assembly - 2 row 12 x 16	FMWXX 18/24
125042	A coil assembly - 3 row 16 x 16	FMWXX 30/36
125043	A coil assembly - 3 row 18 x 16	FMWXX 37
125097	A coil assembly - 2 row 16 x 22	FMWXX 42
125098	A coil assembly - 3 row 16 x 22	FMWXX 48
125099	A coil assembly - 3 row 18 x 22	FMWXX 60
125081	A coil assembly - 4 row 20 x 22	FMWXX 61
125112	hydronic coil assembly w/ pump - 2 row	FMWXX 42/48/60/61
125113	hydronic coil assembly w/ pump - 3 row	FMWXX 42/48/60/61
125114	hydronic coil assembly w/ pump - 4 row	FMWXX 42/48/60/61
125115	hydronic coil assembly w/ pump - 2 row	FMWXX 18/24/30/36/37
125116	hydronic coil assembly w/ pump - 3 row	FMWXX 18/24/30/36/37
125117	hydronic coil assembly w/ pump - 4 row	FMWXX 30/36/37
PS-4-055	piston assembly - .055	FMWXX 18
PS-4-059	piston assembly - .059	FMWXX 24
PS-6-068	piston assembly - .068	FMWXX 30
PS-6-074	piston assembly - .074	FMWXX 36/37
PS-4-080	piston assembly - .080	FMWXX 42
PS-6-084	piston assembly - .084	FMWXX 48
PS-6-092	piston assembly - .092	FMWXX 60
PS-8-092	piston assembly - .092	FMWXX 61
125153	boiler coil assembly w/o pump - 2 row	FMWXX 18/24/30/36/37
125154	boiler coil assembly w/o pump - 3 row	FMWXX 18/24/30/36/37
125155	boiler coil assembly w/o pump - 4 row	FMWXX 30/36/37
125156	boiler coil assembly w/o pump - 2 row	FMWXX 42/48/60/61
125157	boiler coil assembly w/o pump - 3 row	FMWXX 42/48/60/61

FMW Parts List. Revised 4/15/2005. Subject to change without notice.

Part Number	Description	Unit
125158	boiler coil assembly w/o pump - 4 row	FMWXX 42/48/60/61
126055	top door (1p bkr)	FMWXX 18/37
126007	top door (solid)	FMWXX 18/37
125051	Coil door assembly	FMW 18/24
126583	Coil door assembly	FMW 30-36-38
126584	Coil door assembly	FMW 37
126015	filter door	FMWXX 18/37
126051	top door (1p bkr)	FMWXX 42/61
126031	top door (solid)	FMWXX 42/61
125087	Coil door assembly	FMW 42/48
126581	Coil door assembly	FMW 60
126582	Coil door assembly	FMW 61
126029	filter door	FMWXX 42/61
125076	Downflow coil kit	FMW 18/37
125077	Downflow coil kit	FMW 42/61
126013	A – coil drain pan	FMW 18/37
126012	horizontal drain pan	FMW 18/37
126025	A – coil drain pan	FMW 42/61
126036	horizontal drain pan	FMW 42/61

FMW Parts List. Revised 4/15/2005. Subject to change without notice.