FWB Air Handler Parts Price List

Part Number	Description	Unit	Net Price
1821	drain pan	FWB all	
8201	9 x 6 blower housing & wheel	FWBXX 18/24	
8200	10 x 8 blower housing & wheel	FWBXX 30/36/37	
8094	motor - 120 V -1/5 HP	FWBXX 18/24	
8095	motor - 120 V -1/3 HP	FWBXX 30/36/37	
8115	capacitor - 10 mfd / 370V	FWB all	
3925	circulator pump w/ ck valve-120V	FWB all	
8518	circuit breaker-1 pole-15 amp	FWB all	
8432	terminal block	FWB all	
8513	pull out disconnect-10 kw or less	FWB all	
8230	pump relay/aux relay	FWB all (w/o TDR)	
8231	blower time delay relay	FWB all	
8231	pump time delay relay	FWB all	
8247	transformer 120V-40VA	FWB all	
8567	replacement pump cartridge	FWB all	
121040	top front door-breaker	FWB all except -013	
121057	top front door-disconnect	FWB all except -013	
121027	top front door-terminal block	FWB all except -013	
121056	top front door - terminal block	FWB XX-XX-013	
121029	bottom front door-solid	FWB all	
121031	bottom front door-perforated	FWB all	
121052	Secondary Drain Cover	FWB all	
125080	water coil assy w/ pump - 2 row	FWB28/30/32 XX	
125024	water coil assy w/ pump - 3 row	FWB33/35/36/38 XX	
125025	water coil assy w / pump - 4 row	FWB39/41 XX	
125167	water coil assy w / pump - 2 row	FWB XX-XX-013	
129027	water coil assy w/o pump - 2 row	FWB28/30/32 XX	
125021	ref coil assy - 2 row	FWBXX 18/24	
125022	ref coil assy - 3 row	FWBXX 30/36	
125023	ref coil assy - 4 row	FWBXX 37	
PSF-2-55	piston assembly - .055	FWBXX 18	
PSF-2-59	piston assembly - .059	FWBXX 24	
PSF-3-68	piston assembly - .068	FWBXX 30	
PSF-3-74	piston assembly - .074	FWBXX 36	
PSF-4-74	piston assembly - .074	FWBXX 37	
8179	wire harness	FWB all	
8560	hose bib	FWB XX-XX-013	

Effective 11/1/01. Revised 3/21/05.

Subject to change without notice.